

ИНСТРУКЦИЯ ЗА МОНТАЖ НА ОФИС СТОЛ CARMEN 6009

<p>1</p>	<p>2</p>	<p>3</p>	<table border="1"> <tbody> <tr> <td>A</td> <td></td> <td>1 бр.</td> </tr> <tr> <td>B</td> <td></td> <td>5 бр.</td> </tr> <tr> <td>C</td> <td></td> <td>1 бр.</td> </tr> <tr> <td>D</td> <td></td> <td>1 бр.</td> </tr> <tr> <td>E</td> <td></td> <td>1 бр.</td> </tr> <tr> <td>F</td> <td></td> <td>1 бр.</td> </tr> <tr> <td>G</td> <td></td> <td>1 бр.</td> </tr> <tr> <td>H</td> <td></td> <td>1 бр.</td> </tr> <tr> <td>I</td> <td></td> <td>1 бр.</td> </tr> <tr> <td>J</td> <td></td> <td>1 бр.</td> </tr> <tr> <td>K</td> <td> M6*18mm</td> <td>4 бр.</td> </tr> <tr> <td>L</td> <td> M6*30mm</td> <td>2 бр.</td> </tr> <tr> <td>M</td> <td></td> <td>1 бр.</td> </tr> <tr> <td>N</td> <td></td> <td>1 бр.</td> </tr> </tbody> </table>	A		1 бр.	B		5 бр.	C		1 бр.	D		1 бр.	E		1 бр.	F		1 бр.	G		1 бр.	H		1 бр.	I		1 бр.	J		1 бр.	K	M6*18mm	4 бр.	L	M6*30mm	2 бр.	M		1 бр.	N		1 бр.
A		1 бр.																																											
B		5 бр.																																											
C		1 бр.																																											
D		1 бр.																																											
E		1 бр.																																											
F		1 бр.																																											
G		1 бр.																																											
H		1 бр.																																											
I		1 бр.																																											
J		1 бр.																																											
K	M6*18mm	4 бр.																																											
L	M6*30mm	2 бр.																																											
M		1 бр.																																											
N		1 бр.																																											
<p>4</p>	<p>5</p>	<p>6</p>																																											

Максимално натоварване: 70 кг.